


# OPERATING INSTRUCTIONS FOR DIGITAL LEVEL

■ Please read the instructions carefully before using this product and keep it properly for future reference.

## Structure Diagram:



## Button Function:

- ON/REF/OFF button, For short press, it turns on and reset to zero, for long press, it turns off.
- m m/m、 in / ft、 %、 LIGHT button, For short press, it means unit transfer. for long press, it turns on the backlight .
- HOLD、 SOUND button, For short press, it means hold the data or not. For long press, it means sound.

## Features:

- 1.High strength aluminum alloy ruler.
- 2.Digital display, clear and intuitive, with high accuracy.
- 3.The LCD screen is illuminated and can be used normally in a dark environment. Long press the reset button to realize illuminate switch.
- 4.With reset to zero function, absolute level and relative measurement function.
- 5.This digital level has automatic on/off function that will put it into "sleep mode" if it has not been used for 3 min.
- 6.There are two versions available, with laser or without laser  
There are two versions available, with magnets or without magnets  
Please order the one you need before you purchase.
- 7.The magnetic strip at the bottom can be adsorbed to the working face and the measurement is more accurate.

## Technical Data:

- Measuring range:4X90° .
- Resolution:0.05° .
- Accuracy:±0.2° .
- Repeatability:0.1° .
- Battery:2\*AAA batteries.
- Working temperature:0-40℃.
- Working humidity ≤80%.
- Storage temperature:-20-60℃.

## Attention:

- 1.This product belongs to the precision measuring instrument, which should prevent physical damage such as falling and beating, and cannot be used and saved in the environment such as insolation, drenching, high temperature and strong magnetic field, so as to avoid parts failure and inaccurate accuracy.
- 2.Because the product is only suitable for two axis measurement, in the third axis ( the level of the front and back) and horizontal Angle is less than 30° , the LCD will display an error message "Err".
- 3.When the battery pattern is displayed on the side of the display screen, the power is low and the battery needs to be replaced.
- 4.If the product is not used for a long time, it is recommended to remove the battery.

The company has the right of final interpretation, which is subject to change without prior notice.