



SMART LEVEL

The New Industry Standard

Congratulations on your purchase! Our high-precision altimeters, with our app, are changing the industry and becoming the new industry standard! Thank you for being a part of this change. We would love your feedback, testimonials, reviews, and we'd love to follow your journey via social media! Please use the QR code for leaving a review, app download, and ALL our social media accounts. Connect with us for questions/comments/testimonials!

*** If you send us videos/photos/testimonials to Jennifer@SmartLevel.us, we will mail you Smart Level Swag! ***

Directions

- 1. Download the Smart Leveler App.** If you have an iPhone, use the App Store. If you have an Android use Google Play. Download the app called: SMART LEVELER. You can use the QR Code above for easy download.
- 2. To Turn on the display screen, tap the power button once.** To Turn off the display, hold the Power button down for 5 seconds.
- 3. Measurements on display.** After the level is turned on, pressing the Power button will allow you to change measurements from inches to fractions or centimeters. If you let the new measurement sit for 30 seconds and want to readjust it, you will need to turn off the Level and turn it back on and repeat this step.
- 4. ZERO the Level.** Tap Zero once for backlight. **To Zero the level**, hold the ZERO button for 5 seconds, you will hear a beep to verify. *Where you zero the level/display is the reference point/height for your Zero initial reading. Also, please note the reel can be played anywhere (we recommend in the center of your work site), pulling the tubing fully out of the reel is recommended for large sites, lay the reel flat on its back while in use and PRIOR to zeroing.
- 5. Connect the Smart Level to the Smart Leveler App.** To connect the Bluetooth function, press and hold ZERO button, then tap the POWER button, release the Zero button. You should see the small satellite/bars icon displayed, verifying your Bluetooth connection. To turn off the Bluetooth option, hold Zero and tap Power button.
- 6. Adjust Range.** To adjust the Range, hold the Power button, tap Zero, and release Power button. You can adjust the Range up and down using the Power or Zero button individually. After marking your Zero point, you can create a Range based off that point. The Range is displayed until you finish adjusting, after 5 seconds the height will display. For example, if you set the range to ½ inch from your zero point, the Level will inform you if you go above/below that on the display, and a corresponding light will be displayed.

For questions or assistance, please contact us at: Mike@SmartLevel.us / Jennifer@SmartLevel.us / (800) 472-3741